

# QBot Platform

## Connectivity User Manual

*v 1.0 – 29th February 2024*

For more information on the solutions Quanser Inc. offers,  
please visit the web site at: <http://www.quanser.com>

Quanser Inc. info@quanser.com  
119 Spy Court Phone : 19059403575  
Markham, Ontario Fax : 19059403576  
L3R 5H6, Canada printed in Markham, Ontario.

This document and the software described in it are provided subject to a license agreement. Neither the software nor this document may be used or copied except as specified under the terms of that license agreement. Quanser Inc. grants the following rights: a) The right to reproduce the work, to incorporate the work into one or more collections, and to reproduce the work as incorporated in the collections, b) to create and reproduce adaptations provided reasonable steps are taken to clearly identify the changes that were made to the original work, c) to distribute and publicly perform the work including as incorporated in collections, and d) to distribute and publicly perform adaptations. The above rights may be exercised in all media and formats whether now known or hereafter devised. These rights are granted subject to and limited by the following restrictions: a) You may not exercise any of the rights granted to You in above in any manner that is primarily intended for or directed toward commercial advantage or private monetary compensation, and b) You must keep intact all copyright notices for the Work and provide the name Quanser Inc. for attribution. These restrictions may not be waved without express prior written permission of Quanser Inc.

#### Waste Electrical and Electronic Equipment (WEEE)



This symbol indicates that waste products must be disposed of separately from municipal household waste, according to Directive 2002/96/EC of the European Parliament and the Council on waste electrical and electronic equipment (WEEE). All products at the end of their life cycle must be sent to a WEEE collection and recycling center. Proper WEEE disposal reduces the environmental impact and the risk to human health due to potentially hazardous substances used in such equipment. Your cooperation in proper WEEE disposal will contribute to the effective usage of natural resources.



**This equipment is designed to be used for educational and research purposes and is not intended for use by the public.** The user is responsible to ensure that the equipment will be used by technically qualified personnel only. While the end-effector board provides connections for external user devices, users are responsible for certifying any modifications or additions they make to the default configuration.

# Table of Contents

|  |   |
|--|---|
| Table of Contents                            | 2 |
| A. Network Setup                             | 3 |
| i. Router Setup                              | 3 |
| ii. LAN                                      | 4 |
| iii. Wireless                                | 4 |
| iv. Setting Up a Windows Laptop as a Hotspot | 5 |
| B. User Interface                            | 5 |
| i. Direct                                    | 5 |
| ii. Remote                                   | 6 |
| File Transfer                                | 6 |
| Terminal access                              | 7 |

## A. Network Setup

### i. Router Setup

Each QBot Platform Bundle comes provided with a router, router power supply and ethernet cable. The key ports and parts have been outlined in Figure 1 for easy setup.




Figure 1. Router parts and key ports

Set up sequence:

1. Connect the power supply (Figure 1b) provided with the router to the power port on the back of the router (Figure 7d).
2. *Optional Step:* Connect the PC to the router by using the provided ethernet cable (Figure 1c) and one of the four black ports on the back of the router labelled 1 to 4 (Figure 1d).
  - a. Connect the other end of the ethernet cable directly into the PC using an Ethernet port.


**Note: DO NOT** use the yellow port labelled WAN to connect to a PC. This port is used to provide an internet connection to the router, which is not recommended, as the router is configured to optimize local traffic only.

**Note: DO NOT** use an ethernet switch or any other device between the router and the PC

Turn on the router. After a few minutes, the lights on the front of the router (Figure 7a) should start flashing with a white light to indicate to the user that the ports are active.

## ii. LAN

The QBot Platform may be connected to the supplied router or network of your choice using an ethernet cable connected to the 10/100/1000 Base-T Ethernet jack on the side of the QBot highlighted in Figure 2a. In this mode, the LCD will show an ethernet symbol as shown in Figure 2b.



a. Ethernet jack on QBot Platform



b. LCD showing wired connectivity

Figure 2. Ethernet setup with the QBot Platform

The LCD will also show the IPv4 address of the QBot Platform assigned dynamically by the DHCP server on the provided router (if using LAN) or the network of your choice.

## iii. Wireless

The QBot Platform is configured to automatically connect to the router provided with the full QBot Platform Bundle. The wireless access point (AP) settings for the network with the provided router are,

|          |   |  |
|----------|---|--|
| SSID     | - | <b>Quanser_UVS</b> (2.4GHz) or <b>Quanser_UVS-5G</b> (5 GHz) |
| Password | - | <b>UVS_wifi</b>  |

If the QBot Platform was not purchased as part of the Bundle package or if you choose to set up your own network, you will need to manually configure the Wi-Fi. Please keep the following considerations in mind:

1. The QBot Platform can use either the 2.4GHz (full spectrum) or 5GHz bands. The 5GHz band at higher frequencies is disabled on the router provided with the QBot Platform for easy integration with all Quanser products. Ensure that your 5GHz network is broadcast over the channels in the range 36 to 60 and not higher. If you are using your own router, this warning can be ignored.  
**Note:** The 2.4GHz band offers coverage over farther distances but performs at slower speeds. The 5GHz network offers higher bandwidth and data rates over shorter distances.
2. Ensure that your router has the Dynamic Host Configuration Protocol (DHCP) server enabled. This will ensure that the router automatically assigns an IP address to the robot when it connects.
3. To have the QBot Platform connect to a wireless network of your choice, you need to access the Wi-Fi configuration menu in Linux. To access this GUI desktop, you can connect to the QBot Platform using a monitor/keyboard/mouse as described in section B.i - Direct.

Once the wireless connection is established, the LCD will show a wireless symbol as highlighted in Figure 3, as well as the IPv4 address of the platform dynamically assigned by the provided router or the router for the network of your choice. If you are using the provided router, the IP will look like the IP in Figure 4. (192.168.2.X).



Figure 3. Wi-Fi setup with the QBot Platform

#### iv. Setting Up a Windows Laptop as a Hotspot

If you do not have a router available, you could use your windows laptop to create a hotspot.

1. Select **Start**, then select **Settings > Network & internet > Mobile hotspot**.
2. For **Share my internet connection from**, choose the internet connection you want to share.
3. For **Share over**, choose **Wi-Fi** which is the default.
4. Expand the **Properties** section, then select **Edit** and enter a new network name (**Quanser\_UVS-5G**), password (**UVS\_wifi**), and network band (**5G**). Select **Save**.
5. Turn on the **Mobile hotspot** toggle at the top of the Mobile hotspot settings page.
6. Since the name and password of the network are the same as the ones the router would have provided, the robot should connect to it automatically without having to go to the Wi-Fi settings. Make sure to restart your QBot if it was already turned on.

## B. User Interface

#### i. Direct

The QBot Platform can be used directly as a computer. You will need a USB keyboard and mouse, an HDMI cable, and a monitor.

1. Connect a keyboard/mouse to the robot using the USB ports.
2. Using the HDMI port on the side of the robot, connect the robot to the monitor's HDMI port.
3. The network can be set up using LAN, Wi-Fi or a Hotspot as described in section A.
4. The credentials to login are as follow: **username** is "**nvidia**" and the **password** is "**nvidia**".

For applications that require the QBot Platform to be moving or require remote access, a direct setup is not feasible. In such cases, a wireless connection using the router is preferred. For this setup, you could use a PC or the provided Ground Control Station (GCS) (if the QBot Platform was purchased with a bundle). Connect the computer to the same network or connect it directly to the router as in section A.i.

```
>> ping 192.168.2.X -t
```

## File Transfer

To use WinSCP, enter the QBot Platform's IP address as the host name, **nvidia** as the username, and **nvidia** as the password, as shown in Figure 4a. You can now use the WinSCP browsers to transfer files from the computer to the QBot Platform (right browser), shown in Figure 4b. Double clicking a file on the right will automatically transfer a copy of the file to your PC and open it in your default editor. Clicking save in your editor will automatically transfer the saved version back to the QBot Platform.

The screenshot shows two windows side-by-side. On the left is the 'Login' dialog box. It has a 'New Site' button at the top left. The 'Session' tab is active, showing fields for 'File protocol:' (set to 'SFTP'), 'Host name:' (192.168.2.xx), 'Port number:' (22), 'User name:' (nvldia), and 'Password:' (masked with dots). There are 'Save' and 'Advanced...' buttons at the bottom of the session fields. At the very bottom of the dialog are 'Tools', 'Manage', 'Login' (highlighted with a green border), 'Close', and 'Help' buttons. A checkbox at the bottom left is checked and labeled 'Show Login dialog on startup and when the last session is closed'. On the right is a Windows File Explorer window titled 'pi - 192.168.2.3 - WebGCP'. The address bar shows 'C:\Users\Quamr\libraries\python\git\'. The main pane shows a file tree with folders like 'utilities', 'products', 'python', and 'py'. The right pane shows the contents of the '/home/pi/' directory, listing files and folders like 'Desktop', 'Downloads', 'Music', 'Pictures', 'Public', 'Templates', and 'Videos' with their respective sizes and modification dates.

b. WinSCP browser to transfer files

6

If looking to use direct **scp** commands to transfer files from your windows command prompt or powershell directly to the QBot, you can use a command such as,

```
>> scp fileLocationOnHostComputer nvidia@192.168.2.X:/home/nvidia/...
```

## Terminal access

You can use the terminal to connect to the robot. These are just some of the ways to do it.

## PuTTY

Install the PuTTY tool in your machine. Find more information on PuTTY [here](#). If you are familiar with Linux command-line text editors, you can also edit code on the QBot Platform via PuTTY. This software by itself is sufficient to access the file system and execute code that does not require any graphical feedback display.

If you moved files to the robot through WinSCP, you could open a PuTTY terminal directly from the menu there.



To use the PuTTY app directly, open the application and enter the hostname or IP address of the QBot Platform in the hostname field as shown in Figure 5 then click Open. You will be prompted to login (username **nvidia**, and password **nvidia**). Note that you can open more than one PuTTY terminal to the QBot Platform if you need to.




Figure 5. Connecting to the QBot Platform with PuTTY

## SSH

To remotely connect to the robot through the terminal without downloading any software you could use SSH. To use the OpenSSH client on Windows, simply open a PowerShell



window or a command prompt window and run the ssh command. For example, if you want to connect to the QBot Platform via terminal, run the following command in a command prompt or powershell,

```
>> ssh nvidia@192.168.2.x
```

The terminal will prompt you for the password (**nvidia**).

**Note:** **SCP** and **SSH** are both terminal utilities installed in Windows 11, and **WinSCP** and **PuTTY** have graphical interfaces to launch this.

© Quanser Inc., All rights reserved.



Solutions for teaching and research. Made in Canada.